



Installation Manual



RMT

Roof Mount Mobile Audio Console


Contents of package for the RMT Audio Console

Parts List


- 1. Mount kit:** (12) Bolts
(4) Lock Nuts
(4) Gasket Washers



- 2. Wiring kit:** (2) Ring terminals
(2) Butt connectors
(1) Fuse holder
(1) 15A fuse
(1) T-tap
(1) Male connector



- 3. Install kit:** (6) Wire ties
(4) Wire tie mounts




Steps for Installing the RMT

1. Remove the 4 screws from the top of the RMT.
2. Remove the top plate of the RMT. Hold the top plate in the desired location of the Stereo.
3. Use the plate as a pattern to mark the 4 hole locations.
4. Drill $\frac{1}{4}$ inch holes completely through the top of the roof structure you are mounting the RMT up to.
5. For nonconforming or irregular tops, insert the (optional) **foam-kit insert** between the RMT and nonconforming top.

Tractor Tunes has provided 3 sizes of bolts in the bolt kit. Because this is a universal RMT, You will need to determine the proper size for your application.

Always use the supplied sealing washers on the exterior of your top to provide a seal for the bolts. Take your time to install this product. Installing it properly will ensure years of listening enjoyment.

Warning! Tractor Tunes will not warranty any installation of this product. This is an aftermarket product and needs to be installed properly. Failing to drill the correct size holes, over tightening and not using the provided sealing washers will cause damage to the RMT and whatever you are bolting it to.



Wiring Option 1


STANDARD ACCESSORY POSITION INSTALLATION

Installing this way will only allow the stereo to be turned on if the key is in the accessory position. This will also always turn the stereo off when the key is in the off position.

1. With a razor blade, score and then strip away the insulation on the end of the wiring harness.
2. Attach the **green** accessory wire to the factory accessory position on the key ignition switch using the **male connector**.
3. Using a **butt connector**, attach a lead wire of the **fuse holder** to the **white** power wire of the MAC.
4. Then attach the other lead wire of the **fuse holder** to the **positive** lead on the battery, using a **ring terminal**.
5. Install the black wire to the **negative** lead on the battery using the other ring terminal.

CAUTION: Install the 15 amp fuse in the fuse holder after the positive and negative leads are connected to the battery.

WARRANTY VOIDED IF NOT CONNECTED TO A 12-VOLT POWER SOURCE!



Wiring Option 2

CONSTANT POWER INSTALLATION

Installing this way will allow the stereo to play at all times, even if the key is **not** in the on position. If the stereo is installed this way, the stereo does have the ability to drain the battery if the radio is left on for an extended amount of time.

1. With a razor blade score and then strip away the insulation on the end of the wiring harness.
2. Connect the green accessory wire to the white wire before the **butt connector** using the **t-tap** and **male connector**.
3. Then connect the white wire to one end of the **fuse holder** using a **butt connector**.
4. Install a **ring terminal** on the other end of the fuse holder and connect it to the positive lead on the battery.
5. Install a **ring terminal** on the black wire and connect it to the negative lead on the battery.

CAUTION: Install the 15 amp fuse in the fuse holder after the positive and negative leads are connected to the battery.

WARRANTY VOIDED IF NOT CONNECTED TO A 12-VOLT POWER SOURCE!

